

## A-Tech Hydra-Block Penetrating Concrete Sealer

Air and surface temperature must be above freezing during application and for three days after application. Do not apply to hot surfaces or in direct sunlight.

Apply using a low pressure sprayer with fan pattern tip.

1. Remove any paint, sealers, or adhesives on substrate. Clean off any oil, dirt, rust or wax. Remove existing efflorescence or laitance. Mask glass, metal, tiles and plants to prevent overspray.

2. Lightly dampen substrate with water using a mop or sprayer.

3. Shake Hydra-Block before using

4a. Concrete Application-Use 2 -3 light coats.

4b. Concrete Block Application-Use 3-4 light coats.

4c. Clay Brick Application-Use 2-3 light coats.

5. Spray a section at a time. After spraying for 20-30 minutes return to original area and re-apply when surface is still damp.

6a. **Horizontal Application**-Spray sealer in a fine mist until the surface is saturated. Re-apply to fast drying areas to maintain a wet look. Do not allow to puddle or run. Spread any puddles with a roller. Wipe off excess with a wet rag within 10 minutes of application.

6b. **Wall Application**- Begin at bottom and work your way up the wall. Do not allow product to run. Spray sealer in a fine mist until the surface is saturated. Re-apply to fast drying areas to maintain a wet look.

### **After Application:**

1. Ventilate area to allow drying and curing

2. For several days after application loose materials and dirt will be pushed out of the substrate. This is normal. Sweep as necessary.