

## A-Tech Paver Sealer WB

### I. Where to Use

- A. A-Tech Paver Sealer WB is a water-based acrylic sealer used on brick, masonry, stone and concrete pavers. The product forms a strong glossy finish that protects the substrate and stabilizes the sand in the paver joint.

### II. Site Conditions

- A. Substrate surfaces must be dry, clean and free of standing water, grease, oil, other sealers, curing compounds dust, dirt, loose material, frost, ice, and snow.

### III. Application of A-Tech Masonry & Brick Sealer

- A. Substrate and sand must be dry and have no rain for 3-4 hours after application.
- B. Brush excess joint sand off the surface of pavers. Sand should be 1/8" below the surface of the pavers.
- C. Stir before use. Do not thin, product is ready to use.
- D. For best results temperature should be between 50°F-75°F
- E. Apply with a low pressure sprayer equipped with a fan nozzle. Hold the tip 6-8" from the surface of the paver. Apply uniformly leaving no pin holes. OR apply by pouring the material on to the surface and spreading with a squeegee or roller. Ensure all joints are flooded. Do not allow to puddle. First coat coverage is 100-150 ft<sup>2</sup>/gallon.
- F. For gloss finish apply a second coat after the first coat is tack free. Second coat is applied at 200-300 ft<sup>2</sup>/gallon
- G. All surfaces should be covered thoroughly
- H. Avoid application in strong winds over 15 mph
- I. Protect glass and metal from coverage. Remove overspray on metal and glass immediately with soap and water.

### VI. Safety

- A. Review the Material Safety Data Sheet (MSDS) for complete safety information
- B. Wear goggles or approved safety glasses to protect eyes from misting of the membrane. If contact with eyes happens, flush the eyes with water. If irritation persists, seek medical attention.

### VII. Equipment Clean Up

- A. Clean pumps and lines with soap and water before drying.